

Cuisinart®



Instruction & Recipe Booklet Cordless Rechargeable Personal Blender - RPB-100XA

For your safety and continued enjoyment of this product, always read the instruction booklet carefully before using.

IMPORTANT SAFEGUARDS

READ ALL INSTRUCTIONS BEFORE USING

When using any electrical appliance, especially when children are present, **basic safety precautions should always be taken to reduce the risk of fire, electric shock and/or injury**, including the following:

- This appliance is intended for **HOUSEHOLD USE ONLY** and similar applications such as:
 - staff kitchen areas in shops, offices and other working environments;
 - farmhouses;
 - clients in hotels, motels and other residential type environments;
 - bed and breakfast settings
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack experience and knowledge - unless, they have been given instruction and or guidance concerning use of the appliance by a person responsible for their safety.
- Use only on an appropriate benchtop sitting away from flammable materials such as curtains, draperies and walls of similar nature as a fire may occur if comes in contact or becomes covered during operation.
- Do not place on or near a hot gas, electric burner, or in a heated oven.
- To reduce the risk of fire or electric shock, do not operate any heating appliance beneath or near the mounted charging base.
- Do not mount or store blender over or near a portion of a heating or cooking appliance, or a sink/washbasin.
- Never submerge any portion of the base/motor in liquids. Only the blending/mixing blade has been designed for submersion in liquids. If base/motor falls into liquid, remove immediately. Carefully remove, clean and dry base/motor thoroughly before continuing.
- Blades are very sharp. Always handle with care and store blade away from you.
- Never place blade on base unless the tumbler is properly attached.
- Never leave your blender unattended while it is running.
- Twist blade firmly onto tumbler. Injury can result if moving blade accidentally becomes exposed.
- Do not blend steaming-hot liquids as it can be ejected out of the appliance due to a sudden steaming.
- Do not blend carbonated beverages.
- To safely turn motor off release the Power button.
- To avoid damage to the USB cord, do not let cord meet any hot surfaces including a stovetop.
- The USB power adapter and USB cable should be plugged into an electrical outlet away from sink or hot surface.
- Do not use an extension cord. Plug USB power adapter directly into an electrical outlet.
- Unplug the USB power adapter from the outlet before attempting any routine cleaning, assembling, disassembling or cleaning of the charger.
- Do not operate a damaged USB power adapter and replace immediately.
- Recharge only with the USB power adapter specified by the manufacturer. A USB power adapter (5VDC/2000mA output) that is suitable for one type of battery pack may create a risk of fire when used with another battery pack.
- Do not let USB cable hang over edge of table or benchtop.
- Do not expose a battery pack or appliance to fire or excessive heat. Exposure to fire or temperatures above 130°C may cause an explosion.
- Do not incinerate the personal blender, even if severely damaged; the batteries contain lithium ion which may explode in high temperatures and in a fire.

- Do not use a battery pack or appliance that is damaged or modified. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
- Under abusive/extreme conditions leaks from battery cells can occur. If the liquid gets on the skin, (1) wash quickly with soap and water or (2) neutralise with mild acid such as lemon juice or vinegar. If the liquid gets into eyes, flush them immediately with clean water for a minimum of 10 minutes. Seek medical attention
- Recommended ambient charging and storage temperature: 10°C–40°C.
- The use of attachments or accessories are not recommended by Cuisinart may be hazardous.
- Make sure the appliance is off and the motor/blade has stopped completely before taking off attachments, and before cleaning.
- Do not clean with metal scouring pads. Pieces can break off the pad and touch electrical parts, involving a risk of electric shock.
- While cleaning do not try to dislodge any food when blender is plugged in; always unplug it when cleaning.
- Any other servicing should be performed by an authorised service representative.
- DO NOT LEAVE OUTDOORS.

SAVE THESE INSTRUCTIONS BEFORE THE FIRST USE

Before using the Cuisinart® Cordless Rechargeable Personal Blender for the first time, we recommend you wipe it with a clean damp cloth to remove any dirt or dust. Dry it thoroughly with a soft, absorbent cloth and handle carefully.

The batteries have not been fully charged. Before the first use, the batteries must be charged until the 3 blue LED lights are illuminated. See OPERATING INSTRUCTIONS on page 5.

CONTENTS

Important Safeguards.....	2
Before the first Use.....	3
Parts & Features	4
Quick Tips	5
Operating Instructions	5
Cleaning & Maintenance.....	6

PARTS & FEATURES



A. 2x On-The-Go Tumblers
475ml BPA-Free

B. Stainless Steel Blending Blade

C. Tight-Seal Flip Lids

D. Blue Led Battery Indicator Lights

E. Power Button
Push-to-blend, single speed

F. Base/Motor
Rechargeable 7.4 volts of lithium-ion battery

G. Slip-Proof Feet

H. Back of Base/Charger Port
USB compatible

I. Charger/Power Adapter

J. USB Cable

QUICK TIPS

- When using your blending tumblers, ingredients are put in from hardest to softest e.g. ice cubes, frozen fruit, spinach, milk etc.
- Cut most foods into 2-3cm pieces to achieve the most consistent results.
- If food sticks to the sides of the tumbler when blending, stop the blender and carefully scrape down the food and replace blade to continue blending again to combine.
- When blending thicker mixtures, lightly hold down the top of the tumbler to prevent jumping.
- After blending, flip the tumbler over so that the blade assembly is on the top. Gently tap the tumbler a few times to prevent any spillage. Remove the blade and replace with lid.
- Some recipes may require more than a minute of blending. Simply start blender again, once the minute of continuous blending has elapsed.
- This device is equipped with an overloaded protection that automatically shuts down the motor in case of overheating. If all three LED lights start flashing during the process and the motor stops, this means that the overload protection has been activated. Let the unit rest until three LED lights stop flashing around 30 seconds to 10 minutes.
- When pulsing, do not press the Power button on and off more than three times in one cycle. The fourth time, the motor will shut down and LED lights will flash. This will last for about one minute. After the lights stop flashing, you may press the Power on button to power up again.
- If the blade becomes locked by ingredients, it is recommended to reduce the amount of ingredients inside the cup.
- After finishing a blending cycle, it is recommended to let the unit to rest for at least a minute before starting next blending cycle to avoid overheating of unit.

OPERATING INSTRUCTIONS

BATTERY LIFE

Before the first use of this appliance, the batteries must be charged until all 3 blue battery indicator lights illuminate. With a full charge, your blender will run for approximately 20 minutes, depending on the ingredients.

Your Blender will be fully charged in approximately 2 hours.

BATTERY-LIFE INDICATOR

When Battery-Life Indicator/LED Light Bar displays 3 solid blue power lights, battery capacity is 95%.

Battery Capacity	Indicator
70%-95%	First & second lights are solid & third light is flashing.
40%-70%	First light is solid & second light is flashing.
< 40%	First light is flashing & others are off.

NOTE: 95% charged for a lithium-ion battery is considered fully charged.

TOP-UP CHARGE FEATURE

Your Cordless Rechargeable Personal Blender is equipped with a top-up charge feature. If your motor base runs out of power, you can "top-up" your blender:

- Charge for 15 minutes to get **25 seconds of runtime.**
- Charge for 30 minutes to get **1 minute and 45 seconds of runtime.**
- Charge for 60 minutes to get **5 minutes and 45 seconds of runtime.**
- Charge for 2 hours for **20 minutes of runtime** (full charge)

NOTE: Do not leave your blender uncharged for an extended period of time, as it will affect the life of the rechargeable battery.

1. Place food ingredients in the tumbler ensuring you do not fill past the max-fill line.

-
2. Place tumbler on flat surface then attach blade on round opening of the tumbler to turn clockwise until tightened.
 3. Press the Power button once to turn the blender on and begin blending. It will run for one minute if not interrupted. While the unit is running, you can Pulse by pressing the Power button on and off. You may Pulse three times in total. If you Pulse a fourth time, the motor will stop, and LED lights will flash up to one minute. After the lights stop flashing, you may press the Power on button to power up again.

NOTE: Maximum runtime of a single blending cycle is one minute.

4. Press once more to turn off.
5. When you have finished blending, press the Power button to turn OFF. Remove the tumbler from the base.
6. Turn tumbler right-side up then turn blade counterclockwise to remove.

CLEANING & MAINTENANCE

- After every use, clean each part thoroughly.
- Periodically check all parts before reassembly. ENSURE no part is damaged i.e. the tumblers are chipped or cracked.
- Wash all parts in warm, soapy water; rinse and dry thoroughly.
- Alternatively all removable parts are top-rack dishwasher safe
- Squirt a drop of dishwashing liquid into tumbler and fill halfway with warm water. Attach blade and run for 15 seconds.
- Repeat, using clean tap water.
- Carefully disassemble parts and empty tumbler. Rinse and dry all parts thoroughly.
- Wipe the base clean with a damp cloth to remove any residue then dry thoroughly.
- Never submerge the motor base in water or other liquids.
- The base is **NOT DISHWASHER SAFE**.
- Any other servicing should be performed by an authorised service representative.

Cuisinart®

cuisinart.com.au

©2022 Cuisinart
Suite 101 Ground Floor
18 Rodborough Rd
Frenchs Forest NSW, 2086
Australia

Visit our Website:
cuisinart.com.au

Printed in China

Trademarks or service marks of third parties referred to herein are the trademarks or service marks of their respective owners.

IB-20/230B