

# Brodware

## 1.7034.00.0.XX Bottle Trap Installation Guide

### NOTE:

- This bottle trap connects to 40mm DWV PVC drain pipe.
- This bottle trap connects to a 32mm basin waste. However, a 32mm to 40mm basin waste adaptor is included.

1) Confirm that all components and rubber seals are with your bottle trap before proceeding, as per FIG A.

2) Ensure there is 12mm of 40mm waste pipe protruding out past the finished wall face, as per FIG B.

3) Pre -assemble the bottle trap and trial fit. If required, cut down the horizontal tube and vertical tube to suit.

4) Finishing Installing the bottle trap as per FIG C.

5. Check that all fittings are are tight, and test for leaks.

