


140 Can Single Zone Beverage Centre OCB140SB

omega

Designed to Enhance
EST. 1981



Introducing your new 140 Can Beverage Centre



Control Panel

- A. Temperature Display
- B. Power Button
- C. Child Lock Button Combination
- D. Light Button
- E. Plus / Increase Button
- F. Temperature Display Button Combination
- G. Minus / Decrease Button

Before Using Your Appliance

- Ensure that the Beverage Centre is correctly installed following the user manual instructions.
- Remove all packaging, including foam backing and tape securing shelves.
- Before use, wipe all parts of the unit with a warm, soapy cloth, and rinse and dry thoroughly. Place all parts back in the appliance after cleaning.
- Before plugging in and switching on the power for the first time, ensure it settled for at least 24 hours

Operating Advice

- The default temperature is 4°C (39°F).
- Use the Plus / Increase (+) or the Minus / Decrease (–) adjustment buttons to set the desired temperature.
- To turn the light on or off, press the Light button.
- To enable the door-controlled light function, press and hold the Light button for 6 seconds. The display will show 'OP', turning on the door light function.
- To disable the door-controlled light function, press and hold the Light button for 6 seconds. The display will show 'CL', turning off the door light function.
- To switch between Celsius and Fahrenheit temperature display, press the Plus / Increase (+) and the Minus / Decrease (–) buttons simultaneously for 2 seconds. The display will update with the set temperature symbol (°C/°F).
- To lock all buttons press and hold the Power button and the Light button simultaneously for 1 second, repeat this set to unlock the buttons.

Refer to the User Manual, pages 14–15, for a detailed guide on operating your appliance.

Details

Product Dimensions (W, D, H mm): 595 × 580 × 846–876
Warranty Period: 3 Years

Support

Telephone: 1300 11 HELP (4357)
Email: support@residentiagroup.com.au

