

118L Outdoor Beverage Centre

OBF118

omega

Designed to Enhance
EST. 1981



Introducing your new 118L Outdoor Beverage Centre

Installing Your Beverage Centre

Two person installation: Use two or more able-bodied people to move and install the beverage centre. Failure to do so could result in injury.

Before connecting the beverage centre to the power source, let it stand upright for approximately 8 hours. This will allow any refrigerant gases that may have been disturbed during the transportation process to settle and reduce the possibility of a malfunction in the cooling system.

For a complete installation guide, refer to the user manual page 11–12.

Positioning the shelves

Position the shelf supports inside the racks on the sides at your desired levels. You can place the shelves firmly on the supports and begin to load your contents.


Dimensions

Size (mm): 846H × 555W × 496D (+41 handle)

Details

Capacity: 118L
Warranty Period: 3 Years

The Controls



1. Power Button
2. Light Button
3. Digital Display
4. Temperature Scale
5. Increase Temperature
6. Decrease Temperature

Note: To change the temperature scale, press both the Increase and Decrease buttons at the same time for 2 seconds. The newly selected scale will glow.

To turn the unit on: press the Power button.

To turn the unit off: press and hold the Power button for 6 seconds the display will disappear. Note: If the unit is unplugged, turned off or power is lost, you must wait 5 minutes before restarting the unit. If you attempt to restart without waiting, the refrigerator will not start and may damage the compressor.

Support

Telephone: 1300 11 HELP (4357)
Email: support@residentialgroup.com.au

