

esatto

This little Quick Start Guide is everything you need to start using your EUF88W 88L Upright Freezer, so you can kick back, relax & chill out!



Get ready to use your 88L Upright Freezer!

Your Bar Fridge

1. Temperature Control Knob
2. Storage Drawers (x3)
3. Door
4. Adjustable Foot
5. Top Hinge Assembly
6. Bottom Hinge Assembly + Foot



Adjusting the Temperature

To adjust the temperature, use the control knob. Turn the knob to the right for colder temperatures and to the left for warmer temperatures. The dial is marked from 1 to 4, with 1 being the warmest setting and 4 being the coldest setting.

- For summer or if the room is too warm, set the thermostat to 4 for maximum cooling.
- For winter or if the room is too cold, set the thermostat to 1 for minimum cooling.
- For most situations, the recommended setting is in the middle range (between 2 and 3).

Installation Tips

- When starting up for the first time, keep the freezer upright for 2 hours before connecting it to a power supply.
- When you install your appliance, set the thermostat knob to '6' for the first 24–48 hours, after which you can set it to the level that best suits your needs. It is best to wait 24 hours before adding any contents.

Please refer to your user manual pages 9–11 for detailed installation instructions.

Product Details

Dimensions (W, D, H mm) / **553 x 574 x 845**

Volume / **88L**

Energy Rating / **4 Stars**

Warranty / **2 Years**

Register your Esatto product online for a free additional year esatto.house/warranty

Get in Touch

Need help? Contact our friendly support team via the contact details below.

Phone / **1300 11 4357**

Email / support@residentialgroup.com.au

 @esatto.house  @esatto.house

www.esatto.house