


90cm Induction Cooktop

OCI905TZ

omega


Designed to Enhance
EST. 1981



Introducing your new 90cm Induction Cooktop

Cooktop Overview

- A. Cooktop Controls
- B. Ø210mm Zone × 2
- C. Ø180mm Zone
- D. Ø160mm Zone × 2



Cut-Out Diagram

Shown below are dimensions for your cooktop's benchtop cut-out, as required for its installation.

For minimum distance requirements and safety advice, please refer to your supplied User Manual, pages 04–08.



Details

Product Dimensions (W, D, H): 900 × 520 × 58mm
Cut-Out (W, D): 860 × 490mm | Warranty: 3 Years

Cooktop Controls

	Zone Selection Used to select and monitor which zones you would like to cook with.
	Temperature Slider Touching the slider increases or decreases the selected zone's temperature or timer setting.
	Timer Function A kitchen timer and a way to automatically shut off zones after a set period of time.
	Start/Pause Button This function is used to temporarily pause cooking, without having to power off.
	Keep Warm This function lowers a zone's heat setting to keep food warm after cooking.
	Child Safety Lock Disables cooktop controls to prevent use, such as accidental activation by children.
	Boost Function Used to increase a zone's heat setting to the maximum level for up to 5 minutes.
	Power Button This button is used to easily power the cooktop both on and off.

For a detailed guide on operating your Omega cooktop, please refer to your supplied User Manual, pages 18–28.

Support

Telephone: 1300 11 HELP (4357)
Email: support@residentiagroup.com.au

