

60cm freestanding dishwasher, dark stainless steel, with 15 place settings, AutoDoor, 8 wash programs including SensorWash programs, FastDry system, FlexTray cutlery tray, height adjustable baskets when fully loaded and 45dB operation.





Product Details

FEATURES

15 place settings A huge 15-place setting capacity	AutoDoor	FastDry FastDry ensures hot steam is removed from the dishwasher, to ensure spotless dishes in no time.	FlexTray
Wash programs - 8	SensorWash	Fast wash programs	Height adjustable upper basket
Time Save program	Water safety system	Wash progress indicator	Delay Start - 1 - 24 Hours
Quiet operation	Half load option	Extra fast option	Extra silent option

BENEFITS

Dry dishes every time

Say goodbye to wet dishes and hello to perfectly dry, sparkling results with AutoDoor. At the end of the wash cycle, AutoDoor* springs into action, automatically opening the dishwasher door to allow a powerful burst of air to circulate throughout the interior. This accelerates the drying process, effectively eliminating moisture and leaving your dishes spotless and streak-free. No more towel-drying or waiting for dishes to air dry on the rack, with AutoDoor your dishes are ready to be put away immediately.*Activate AutoDoor when you select the Energy Saver Option on your dishwasher. Energy Saver option can be activated on all programs except PreWash and Steam programs

Fast drying time

Say goodbye to damp dishes with our FastDry system, designed to swiftly whisk away humid air for sparkling dry results every time. Our system dehumidifies hot steam before expelling it from the dishwasher, ensuring minimal humidity remains. With FastDry, enjoy spotless streak free dishes in no time.





Adjusting the right cycle for you

It doesnt matter if youre washing your delicates or your daily load, the sensors in our dishwasher detect the level of grime on your dishes and adjust the cycle length and temperature to ensure best results every time. Choose from Delicates, Daily or Heavy and allow the dishwasher to do the rest.

Superior cleaning every wash

Wash all your dirty dishes together with DualWash. With lower water pressure and temperature in the top basket, perfect for glassware and higher pressure and temperature in the lower for pots and pans, you can wash all in one without compromise. Plus, the inverter technology will keep noise to a minimum, so you can continue doing what you love.

Adjustable convenience

Say goodbye to awkward stacking and hello to effortless organisation with our innovative FlexTray. With a simple slide, you can adjust the top cutlery tray to half its size, allowing you to effortlessly stack tall glasses and bulky items, ensuring every item gets the perfect clean.

Make room for larger items

Those extra large items can now fit with ease in the bottom basket with our height adjustable upper basket. Even if its fully loaded, it's easily lifted to fit the most awkward item underneath.



Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	2
Type of Dishwashers	freestanding
Design family (eline)	Family Size Dishwasher
Place settings	15
Drying system	turbo dry
Number of spray arms	2
Top shower	Yes

SPECIFICATION

Water Efficiency Star Rating	5
WELS Registration Number	D02963
Water consumption (litres)	12.2
Energy Efficiency Star Rating	4.5
Energy consumption cold water (kWhr/yr)	245
Noise level dBA	45
Water supply	cold or hot (maximum 60°C)
Basket colour	grey
Service cord length	180

DIMENSIONS

Total height (mm)	850
Total width (mm)	598

WASH PROGRAMS

Number of Programs 8



DIMENSIONS

Total depth (mm)	598
Height adjustment (mm)	20

WASH PROGRAMS

Programs	fast 30min,Eco 50°C,Time Save 50 minutes,SensorWash Delicate (30 - 50°C),SensorWash Daily (50 - 60°C),SensorWash Heavy (60 - 70°C),Delicate,Dual Wash 60°C
Wash option	EnergySaver,Tablet,Power half load (3 mode),Extra hygiene,Extra silent,Extra fast,Delay start (1-24 hours)

CONTROL PANEL

Control panel type	Push button electronic,LED Display
Top mounted control panel	Yes
Control panel finish	black
Display indicators	time remaining,wash program,wash progress,rinse aid,program selected,lock,EnergySaver,delay start,on/off ,tablet function

FEATURES

Other Features	child lock on control panel,Soil Level Sensor,AutoDoor
Water safety system	overfill protection,bottom catchment tray,anti-flood protection,aqua control
Filter system	3 stage
Dispenser	detergent,rinse aid

EXTERIOR

Door finish	dark stainless steel
Side colour	Dark silver

UPPER BASKET

Upper basket features	height adjustable on full load
Foldable cup shelves	4





EXTERIOR

Plinth colour (kickboard) Dark stainless steel

UPPER BASKET

Foldable Racks 6

LOWER BASKET

Foldable Racks 4

THIRD TRAY

Tray features Cutlery Tray, Sliding

HOSES

Inlet hose length	170
Drain hose length	180
Inlet hose length (metres)	1.47
Drain hose length (metres)	1.80
extension hose	spare part

SHIPPING

Shipping Weight (Kg)	50
Pack Dimensions Height (mm)	881
Pack Dimension Width (mm)	644
Pack Dimension Depth (mm)	661

STUFFING QUANTITIES


20ft	48
40ft	102
40ft HC	153



Dimensions

Freestanding Dishwasher

WSF6602WB | WSF6602XB WSF6604WB | WSF6604XB WSF6606XB | WSF6606KXB WSF6608XB | WSF6608KXB



IMPORTANT

These dimensions are a guide only. All measurements are in millimetres (mm). For complete installation instructions, refer to the manual provided with product.



Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous productdevelopment, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products PtyLtd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640 fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230 fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz